



## UKST075CB (7.5 Litre) Copper / Bronze Sediment Trap Installation & Maintenance Guide

### Installation

The UKST075 (7.5 Litre) Copper / Bronze Trap Kit is supplied with rigid inlet and outlet connections. The trap should be sat on a removable plinth / baton (not supplied) to enable the trap body to be easily separated from the lid once the sealing clamp is undone.

#### TRAP INLET

The Trap Inlet is supplied in 3 parts:

1½" BSP Male x 40mm Solvent Weld Adaptor  
40mm x 350mm Sink Tail Piece  
1½" x 40mm Cap & Lining

#### TRAP OUTLET

The Trap Outlet is also supplied in 4 parts:

1½" BSP Male x 40mm Solvent Weld Adaptor  
40mm Male x 40mm Female Elbow (the male end can be cut to suit installation)  
40mm x 90mm Waste Pipe Length (cut to required length to suit your installation)  
40mm Universal Compression Coupler

Use the appropriate jointing materials & compounds; PTFE Tape, solvent weld cleaner & adhesive following the relative manufacturers instructions. These jointing materials are not supplied with your sediment trap kit.

The fittings are supplied loose for ease of installation and require solvent cleaning & welding to the main waste to suit your trap installation. Failure to use the appropriate materials could result in water leaks.

Before filling the UKST075 Copper Bronze Trap, make sure all of the joints have been made correctly using the correct materials and where adhesives have been applied, the correct amount of drying time has lapsed in accordance with the manufacturers' directions. Also make sure that the drain valve is closed.

### Cleaning Instructions

- 1 To clean the trap, drain off excess water into a suitable container from the "drain tap" to reduce water pressure.
- 2 Open stainless steel clamp by loosening black handle and push "T" bolt clear of clamp.
- 3 The trap is now ready for removal for cleaning. The trap must be moved / lifted in accordance with "Health & Safety" guidelines.
- 4 Clean out the trap appropriately, disposing of waste material in a responsible manner.
- 5 Reverse above steps to re-install the trap, periodically coating Vaseline or similar petroleum jelly on both sides of gasket to maintain a good seal.
- 6 Check for leaks.

